





Part List & Assembly




SHROOMERs

Part List & Assembly



SHROOMERS

Part List & Assembly



Suggested Materials

1. Glue


- Zap-A Gap brand, Medium. Works great to assemble the grey resin parts. Crazy Glue works as well.

- Formula '560, Canopy Glue. Use to glue together your clear resin parts.

2. Cleaning Solution

- Simple Green or any Dishwasher soap. In order to give a wash to your resin parts to clean off mold release residue before painting or gluing.

Produced by:



Designed by:



Sculpted by:

